Dear Dale

Your question on the phone on Friday 3rd. May 2013 regarding the different types of W 6 Class Tramcars the following information is the best I can get from old Data sheets.

SW6 851 – 889 Reversible Seating in Saloons. Ref. Drwg. R 4771 all modified to Tasker.

890 – 939 Tubular Seating in Saloons (Old style Bus Seats)

940 – 1000 As W5 Seating in Saloons Ref. Drwg. R 4678 B

Seating

851 – 889 48 Seated 2 Saloons = 32 Smoker = 16 Total 48 Crush Load = 150

890 – 939 52 Seated 2 Saloons = Smoker = Total Crush Load =

940 – 1000 52 Seated 2 Saloons = 52 Smoker = 16 Total 48 Crush Load = 150

W6 ? defferent loss engines? - what other John bridenux night know. defferences?

Al always Al - not As