

MELBOURNE AND METROPOLITAN TRAMWAYS BOARD.

PERMANENT WAY DEPARTMENT.

CARE OF PLANT.

INSTRUCTIONS TO OPERATOR OF POWER SAW.

THE OPERATOR IS REQUIRED TO:-

(A) DAILY - (prior to using saw)

Check over machine for loose bolts, joints, connections and other defects.
Check safety guard protecting saw.
Check fuel in tank and water in water jacket.
Check oil in engine sump.
Check lubrication of all greasing and oiling points.
Level up machine before running it.
Adjust tension of driving belt (which should be loosened at end of every shift).

(B) GENERALLY

Keep saw and bench in a clean and tidy condition.
Grease wheels of machine before travelling.
Order daily, through the Sub-Foreman or Ganger-in-Charge, all necessary supplies of fuel, oil, etc.
Order the services of a fitter, if required, through the Sub-Foreman or Ganger-in-Charge, who will make the necessary arrangements through Victoria Parade Office or Depot.

LUBRICATING OIL REQUIRED.

For Engine - S.A.E.50.

[Handwritten Signature]
..... PERMANENT WAY ENGINEER

..... 21 JUNE 1949. DATE